




## FL LED Commercial Flood Light


### Slipfitter Mounting

1. Connect the wires to L / N / GND
2. Remove the cover and adjust the bracket to the desired angle
3. Install the bracket on the pole and fix it with screws




### Yoke Mounting

1. Connect the wires to L / N / GND
2. Mount fixture to surface using the hole pattern provided on the trunion bracket.
3. Loosen center bolts and set screw.
4. Rotate fixture to desired aiming position and tighten center bolts.
5. Tighten set screw.
6. Refer to wiring diagrams for power connection.



### Power and CCT selectable version

1. Remove the 1/2" screw plug on the bottom of the fixture.
2. Select Power(White) and CCT(Black) by sliding the respective switch to the desired value according to the figure.
3. Replace the 1/2" screw plug and tighten with a flat head screwdriver.



## TROUBLESHOOTING

### Turn off power before continuing.

1. Light does not come ON.
    - A. Check if circuit breaker tripped.
    - B. Confirm wall switch is ON.
    - C. Check that if the wiring to the unit is loose.
    - D. Check that the line voltage at the fixture is correct.
    - E. Confirm wiring is properly secured.
  2. Light cycles ON and OFF continuously.
    - A. Check the photocell if sensing reflected light.
  3. Light stays ON.
    - A. Be sure the photocell, if used, is functioning properly.
- If light still does not work after checking, contact customer service.

## WIRING DIAGRAM

For 1-10V dimming version, please check wiring diagram below.

