ORE LIGHTING

TSPL LED Strip Linear Light

- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warnings and instructions included with and on the fixture box and all fixture labels.
- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- Commercial installation, service and maintenance of luminaires should be performed by a qualified licensed electrician.
- For the installation: If you are unsure about the installation or maintenance of the luminaires, consult a qualified licensed electrician and check your local electrical code.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- All wiring connections should be capped with UL approved wire connectors.

- Avoid direct eye exposure to the light source while it is on.
- Account for small parts and destroy packing material, as these may be hazardous to children.
- Risk of burn. Disconnect power and allow fixture to cool before changing bulb or handing fixture.


NOTICE: Green ground screw provided in proper location.Do not relocate.

NOTICE: Minimum 90° supply conductors.

NOTICE: Specifications and dimensions subject to change without notice.

NOTICE: Suitable for Dry or Damp location


General Wiring Diagram




ORE LIGHTING

Surface Mounting


1.Take out the light fixture and accessories package from the box.




3. Open the module board down.




5. Wire to mian power through the junction box.




2.Fix the baffle on the lamp.



4.Fix the lamp to the ceiling with the plastic sleeve and screws provided.




6.Assemble the module board upwards. The installation is completed.




ORE LIGHTING

Cable Suspended Mounting


1.Take out the light fixture and accessories package from the box.




3.Connect the V-hook to the lamp.




5.The installation is completed.



2.Attach V-hooks to the cable.




4.Connect the AC wires.




Additional Accessories

Emergency Battery Back-up




General Wiring Diagram






Additional Accessories


 Microwave Sensor/Bluetooth BRI810-B-M10



General Wiring Diagram



Field-Adjustable Wattage & CCT




The end users may adjust the color temperature and lumen output respectively by the two DIP switch.Each DIP switch is accommodated with 3 options (left, middle and right),corresponding to 3 color temperatures and 3 powers respectively, which can perform the desired color temperature and lumen output combination.

1.DIP switches are located onto the side of the fixture.

2.Select a wattage and color temperature by sliding switch left or right respectively to the desired value.

Field-Adjustable Wattage & CCT



The end users may adjust the color temperature and lumen output respectively by the two DIP switch.Each DIP switch is accommodated with 3 options (left, middle and right),corresponding to 3 color temperatures and 3 powers respectively, which can perform the desired color temperature and lumen output combination.

1.DIP switches are located onto the side of the fixture.

2.Select a wattage and color temperature by sliding switch left or right respectively to the desired value.